

Instructions Sonodore AP-25, AP-32

Acoustic Pressure Equalizer, Ø25mm, Ø32mm balls for RCM-402 and CCM-65.

AP-25 Ø25mm

- Remove the grid of the microphone
- Gently push the microphone through the ball
Pay attention to the position: *the little flat surface of the ball is the back*
Take care of the membrane!
- Screw the PG-88 grid on the microphone
- Push the ball to the front.
- *The grid will stick out about 1,5mm*

Removing

- Push the ball to the back
- Unscrew the grid
- Remove the ball
- Screw the normal grid on the microphone

Also the ball can be left on the grid.

AP-32 Ø32mm

- Remove the grid of the microphone
- Gently push the microphone through the ball
Pay attention to the position: *the little flat surface of the ball is the back*
Take care of the membrane!
- Screw the PG-78 grid on the microphone
- Push the ball to the front.
- *The front of the ball must be flat*

Removing

- Push the ball to the back
- Unscrew the grid
- Remove the ball
- Screw the normal grid on the microphone

Also the ball can be left on the grid.