



### **Talk Back and light system for the 12 channels analog mixer**

- Connect the Doggy to the Doggy input of the mixer
- Screw the Fostex speaker on a microphone stand
- Connect the TB out of the mixer to the XLR input of the Fostex with a normal microphone cable  
(The TB out is mono, pin 2=hot pin 3=cold)
- Connect the TB RC of the mixer to the jack of the Fostex with a normal line cable (2=tip 3=ring)
- (The volume on the Fostex is expired)
- Switch the power on of the mixer and the Fostex
- The red button on the Doggy is the Talk Back switch
- The yellow button on the Doggy is the light switch
- The Talk Back potentiometer on the mixer is the volume of the internal microphone

For Tape to Talk Back:

(The Tape to TB is mono)

- Push the Tape to Talk Back switch.
- Turn the Tape to TB potentiometer for volume

In emergency situation: a normal active loudspeaker can be connected to the TB out